

RECOMMENDATIONS

- Apply only to clean, sound, dry and properly prepared substrates.
- Application and curing times are dependent upon ambient and substrate conditions.
- Minimum ambient and substrate temperatures are 5°C (41°F) at the time of application. However, it is not advisable to apply the material if the temperature is below 10°C (50°F).
- Maximum ambient and substrate temperatures are 35°C (95°F) at the time of application.
- Substrate temperature should be greater than 3°C (5°F) above the dew point.
- Do not apply material if the relative humidity exceeds 85%.
- Dispose of waste materials in accordance with government regulations.
- Clean all equipment immediately after use with scouring pads and acetone. Hardened material will require mechanical means for removal.

PRECAUTIONS

- The use of safety glasses and impervious gloves is required during application.
- Avoid contact with all liquids as they may cause skin and/or eye irritation. In case of contact, flush the area with copious amounts of water for at least 15 minutes and seek medical attention.
- Wash hands thoroughly with soap and warm water after use.
- Use only with adequate ventilation.