



## APPLYING FLEXISECURIT ER-SO

1. Pour the contents of the pail into a bead on the floor where it can be applied.

**Note:** It is important to pour subsequent beads of material into existing, fresh Flexisecurit ER-SO already applied. This will eliminate potential batch lines in the finished product.

2. Apply the material to the substrate using a 13 mm x 13 mm (1/2 in. x 1/2 in.) notched trowel. To achieve the proper, uniform thickness, hold the trowel at approximately 45°, floating the notches over the surface of the substrate.

**Note:** It is critical to apply the Flexisecurit ER-SO at 2.2 m<sup>2</sup> (23 ft<sup>2</sup>) per unit. This will ensure the proper thickness.

3. After the material is trowelled, a spike roller is used to roll the material. The use of a spike roller allows air to escape and levels the surface of the material. Flexisecurit ER should be spike rolled a minimum of six times (forward and back) to eliminate any entrained air.

## RECOMMENDATIONS

- Apply only to clean, sound, dry and properly prepared substrates.
- Application and curing times are dependent upon ambient and substrate conditions.
- Minimum ambient and substrate temperatures are 5°C (41°F) at the time of application. However, it is not advisable to apply the material if the temperature is below 10°C (50°F).
- Maximum ambient and substrate temperatures are 35°C (95°F) at the time of application.
- Substrate temperature should be greater than 3°C (5°F) above the dew point.
- Do not apply material if the relative humidity exceeds 85%.
- Dispose of waste materials in accordance with government regulations.
- Clean all equipment immediately after use with scouring pads and acetone. Hardened material will require mechanical means for removal.

## PRECAUTIONS

- The use of safety glasses and impervious gloves is required during application.
- Avoid contact with all liquids as they may cause skin and/or eye irritation. In case of contact, flush the area with copious amounts of water for at least 15 minutes and seek medical attention.
- Wash hands thoroughly with soap and warm water after use.
- Use only with adequate ventilation.